

Dear Customer,

Thank you for purchasing our remote control **Lauson**. Please read and follow these instructions, in order to avoid damaging the item.

## PRODUCT DETAILS



<b>POWER</b>	Turn ON/OFF
<b>LED LIGHT</b>	Operation light
<b>AV</b>	Audio / Video option
<b>MUTE</b>	Turn ON / OFF the sound
<b>NUMBER KEYS</b>	Choose stored stations
<b>BACK</b>	Previous
<b>II / ►</b>	Pause / Play playback
<b>PAGE +/-</b>	Next / previous page of Teletext
<b>◀◀ / ▶▶</b>	Back / Next
<b>■</b>	Stop playback
<b>PIP</b>	Picture in picture
<b>SLEEP</b>	Sleep mode
<b>i</b>	View information
<b>FAV</b>	Favorites / bookmarks

<b>GUIDE</b>	Electronic Program Guide (EPG)	<b>TV</b>	TV media selection
<b>+ VOL -</b>	Lower / increase the volume	<b>SAT</b>	SAT media selection
<b>ALL OFF</b>	Turn everything OFF	<b>DIRECTIONAL KEYS</b>	Navigation
<b>▲ P ▼</b>	Next / Previous channel	<b>OK</b>	Confirm
<b>LEARN</b>	Learning button	<b>DVD</b>	DVD media selection
<b>MENU</b>	Display the menu	<b>AUX</b>	AUX media selection
<b>TEXT</b>	Display / Clear Teletext	<b>COLOR KEYS</b>	Individual key configuration
<b>EXIT</b>	Quit	<b>●</b>	Recording

**Note:** URC means UNIVERSAL REMOTE CONTROL and RC means REMOTE CONTROL

## IMPORTANT NOTES

1. It is necessary to put the batteries before you connect the USB cable with URC to PC.
2. For compatibility with many different types of equipment some buttons may have no effect
3. If You could not find your model exact same in the name. Please, choose the same series in the same brand. If still cannot find it and you have the original RC, please use learning mode.
4. Do not expose your URC to dust, strong sunlight, humidity, high temperature or mechanical shock and corrosive cleansers
5. Do not use old and new batteries together as old batteries tend to leak.
6. Lauson warrants that the product will be free from defects in materials and workmanship under normal use. In the event of a defect, please contact us to (+34) 93 453 62 22 or the nearest selling point. We do not cover any damage that may arise from improper use of the item of the disregard of the safety instructions

## DOWNLOADING THE CODES

1. Download the software from website [www.lauson.es](http://www.lauson.es), and follow it to install software to your PC successfully.
2. Connect the cable with URC to your PC well.
3. Press and hold 3 seconds [ < ] and [ > ] keys on URC in the same time, LED keep flashing.
4. Follow the steps to find the correct device / brand / model to download the correct codes for the device you want to program it .
5. After it is successful downloaded, LED flash twice and go off.
6. Stop the connection with USB cable to PC and try the functions are correct. If not, follow the step 1-4 to find the another codes.

**Note:**

1. In 30 seconds, if no any downloading , it exit automatic. You need to follow Step 1-6 again.
2. If you could not find the exact model number in the code library you could find the similar model No. in the list and try it.

## LEARNING FUNCTION, COPY ORIGINAL RC TO THE URC

Warning: program one device at a time!

1. Turn on the device to be programmed.
2. Press and hold the [LEARN]key around 5 seconds until LED goes on . Then release.
3. Press and release the Device key( eg. [ TV ] key, LED flash once.
4. Hold the URC receiver point with the original RC receiver point within 1-2cm.Press the key on URC which is to be copied and release, LED flash fast. Then press the key of original RC. LED flashes trice and keeps on. And then follow the above to learn more keys.
5. Press[Learn] immediately to confirm. LED turns off. Try the functions correct or not. If not , copy again . In 30 seconds , if no any key pressing , it exit automatic. You need to follow Step 1-5 again.

Estimado cliente,

Gracias por adquirir nuestro mando a distancia **Lauson**. Por favor, lea y guarde estas instrucciones para evitar dañar este producto.

## DETALLES DEL PRODUCTO



<b>POWER</b>	Encender / Apagar
<b>LED LIGHT</b>	Indicador de luz
<b>AV</b>	Opción de Audio / Video
<b>MUTE</b>	Encender / Apagar el sonido
<b>NUMBER KEYS</b>	Escoger canales configurados
<b>BACK</b>	Atrás
<b>   / ▶</b>	Parar / Reproducir
<b>PAGE +/-</b>	Página siguiente / anterior de Teletexto
<b>◀ / ▶</b>	Atrás / Siguiente
<b>■</b>	Detener reproducción
<b>PIP</b>	Imagen en Imagen
<b>SLEEP</b>	Modo de suspensión
<b>i</b>	Mostrar información
<b>FAV</b>	Favoritos / marcadores

<b>GUIDE</b>	Guía electrónica (EPG)	<b>TV</b>	Tecla configurada TV
<b>+ VOL -</b>	Subir / Bajar el volumen	<b>SAT</b>	Tecla configurada SAT
<b>ALL OFF</b>	Apaga todo	<b>DIRECTIONAL KEYS</b>	Teclas de navegación
<b>▲ P ▼</b>	Canal siguiente / anterior	<b>OK</b>	Tecla de confirmación
<b>LEARN</b>	Botón de aprendizaje (copiar)	<b>DVD</b>	Tecla configurada DVD
<b>MENU</b>	Mostrar el menú	<b>AUX</b>	Tecla configurada AUX
<b>TEXT</b>	Mostrar / Cerrar teletexto	<b>COLOR KEYS</b>	Conf. de teclas individual
<b>EXIT</b>	Salir	<b>●</b>	Grabación

**Nota:** URC quiere decir MANDO A DISTANCIA UNIVERSAL y RC quiere decir MANDO A DISTANCIA

## NOTAS IMPORTANTES

1. Es necesario poner baterías antes de conectar el cable USB al URC a el PC.
2. Para compatibilidad con muchos tipos diferentes de equipos, algunos botones pueden no tener ningún efecto
3. Si no pudo encontrar su modelo exacto, por favor, elija la misma serie en la misma marca. Si no puede encontrarlo y tiene el RC original, utilice el modo de aprendizaje (copiar).
4. No exponga su URC al polvo, luz solar fuerte, humedad, alta temperatura o choque mecánico y limpiadores corrosivos
5. No use pilas viejas y nuevas juntas ya que las baterías viejas tienden a tener fugas.
6. Lauson garantiza que el producto estará libre de defectos en materiales. En caso de defecto, contáctenos al (+34) 93 453 62 22 o al punto de venta más cercano. No cubrimos ningún daño que pueda surgir por el uso incorrecto.

## DESCARGA DE CÓDIGOS

1. Descargue el software del sitio web [www.lauson.es](http://www.lauson.es) y siga las instrucciones de instalación en su PC.
2. Conecte apropiadamente el cable al URC y su PC.
3. Presione y mantenga durante 3 segundos las teclas de [**<**] y [**>**] en URC al mismo tiempo, el LED empezará parpadeando.
4. Siga los pasos para encontrar el dispositivo / marca / modelo correcto para descargar los códigos en el dispositivo
5. Después de que se descargue con éxito, el LED parpadeará dos veces y se apagará.
6. Desconecte el cable USB y pruebe que las funciones sean correctas, de lo contrario, siga los pasos 1-4 para buscar otros códigos.

**Nota:**

1. En 30 segundos, si no hay ninguna descarga, saldrá automáticamente. Debe seguir el Paso 1-6 nuevamente
2. Si no pudo encontrar el código del modelo exacto en la biblioteca de códigos, podría encontrar un número de modelo similar en la lista y probarlo.

## FUNCIÓN LEARNING (APRENDIZAJE), COPIAR FUNCIONES DEL MANDO ORIGINAL AL URC

**Advertencia:** ¡ programe un solo dispositivo a la vez!

1. Encienda el dispositivo para programarlo y mantenga presionada la tecla [**LEARN**] alrededor de 5 segundos hasta que el LED se encienda, después suelte la tecla.
2. Presione y suelte la tecla de dispositivo [por ejemplo, la tecla TV], el LED parpadeará una vez.
3. Mantenga el punto del receptor URC con el punto receptor RC original a una distancia de de 1-2 cm. Presione la tecla en URC que se va a copiar y suelte, el LED parpadea. Luego presione la tecla del RC original. El LED parpadeará y se mantendrá encendido. Para configurar más teclas, siga los pasos anteriores. Presione [**Learn**] inmediatamente para confirmar, el LED se apagará. Pruebe las funciones. Si no, copie de nuevo dentro de 30 segundos, si no hay ninguna tecla presionada, saldrá automáticamente del modo LEARNING y deberá seguir el Paso 1-5 nuevamente.