

Specifications

The true wireless stereo Bluetooth sound (TWS), individual left and right channel with HIFI sound.

Before using, make sure to place the headphones in the charging box and plug the charge box to any power supply.

Pairing

- Before linking, delete any previous record of the **EH223/EH224** on the device.
- Turn off the Bluetooth function of your mobile phone, tablet or computer device.
- **Pairing with one earbud:**
 - Activate the Bluetooth on your mobile phone, tablet or computer device..
 - Find the model **EH223/EH224**
- **Pairing with two earbud:**
 - Activate the Bluetooth on your mobile phone, tablet or computer device.
 - Find the model **EH223/EH224**

* Note: place both headphones, close to ease the connection process. There will be a voice message or a sound notifying that the connection has been successfully

** Note: Every headphone has their own function.

*** Note: headphones will turn off automatically after a while if there is no connection.

**** Note: after the first earbud connection, the devices (mobile phone, tablet or computer) will connect automatically when the whole set is switched on.

***** Note: **In case that only one of the two is linked during the process, turn on the second headphone and wait a couple seconds, if it not working, press the button "R" twice.**

Usage

1) Making phone calls:

When making calls, if there is any incoming call, it broadcast calling numbers. To answer, press once the multifunction button and to refuse the call, hold for a short time the multifunction button.

2) Listening to music:

Press once the power button to stop /play the music. Last song, double-click on the right ear and next song, double-click on the left ear.

3) Power ON/OFF:

- To turn ON/OFF the headphones in the charging box,
- Open the charging box or remove the headphones from the charging box, then they will turn on themself.
- Put the headphones back in the charging box and close the charging box, then they will turn off themself.
- To turn ON/OFF the headphones out of the charging box,
- Press the multi-function button for 3 seconds.

4) Activate voice assistance:

Press left ear multi-function button for 3 seconds.

5) Charging:

There will be a reminding sound when battery is low. When the earbuds or charging case is taking charge, the led would be in blinking color, and turn stand when it is fully charged.

Warning

- 1) Do not overuse these headphones or press them too hard, keep them away from moisture and heat.
- 2) Try to keep the headphones away from Wi-Fi networks, routers or other high frequency transmission equipment, as they could interrupt the signal reception.
- 3) Use this handset within a range of (10 m) as the connection will be more effective. Try to avoid obstacles between the connected devices, the signal between the device and the headphones may be interfered due to the lack of battery of one or both devices.
- 4) Use this Bluetooth headset to connect any device with BT function

WARRANTY CONDITIONS

Thank you for purchasing this product. Lauson guarantees the proper functioning of its products for a period of 2 YEARS from the date of purchase, being responsible for any lack of conformity that manifests within this period, including the repair of the defects or the replacement of the product within the Union European

CLAIM PROCEDURE

The holder of the guarantee may contact the technical service by telephone at the number (00) 34 934 536 222 or visiting our Lauson website: www.lauson.es or by going directly to the purchasing center.

Before claiming your rights as a consumer, make sure that the product meets the following requirements.

1. The guarantee will be valid if it is presented duly completed with the reference of the model, serial number, date of purchase and establishment data. Being an essential requirement that is accompanied by the purchase ticket.
2. In case of sending to repair the equipment, it must be in the same conditions (packaging, accessories, manuals ...) in which it was purchased, except for natural deterioration due to use. The guarantee does not cover damages caused by transportation due to inadequate packaging.
3. Lauson reserves the right to refuse the guarantee in the event that some of the requested information is not specified, is not legible or is damaged.
4. Damages or malfunctions caused by catastrophic causes, falls and blows due to incorrect use by the user, as well as erroneous feeding by energy sources or parts subject to natural wear and tear due to improper use are not covered by this guarantee.
5. This product will lose its guarantee if it is handled by technicians or workshops outside our company.
6. This guarantee is valid only in scope of the European community. The warranty terms contained in this certificate do not exclude, restrict or modify the rights that legally correspond to the buyer by application to Royal Legislative Decree 1/2007 of November 16.

LAUSON



- BEFORE USING THIS PRODUCT READ THE INSINSTRUCTIONS CAREFULLY.

